



Flash-Vent™ FLEX

Vinyl Drainage Plane Flashing

Key Properties

- A polymeric flashing with drainage plane
- Will not clog with mortar
- Will not support mold growth
- Low profile and non staining
- Easy to install
- Economical to use
- For use with
 - Manufactured Stone
 - Stucco
 - Thin Brick
 - EIFS
 - Brick
 - Fiber Cement



Rolls are available
in widths of 6", 9",
12", 18", 24" and
36" by 40'

Applications

All exterior veneer penetrations and terminations including:

- Cavity wall construction
- Wall to foundation transitions
- Window sills and headers
- Deck terminations
- Cladding transitions to stone, stucco or thin brick
- Columns and wall bases
- Above ground stucco or plaster terminations

Installation For Veneers

- Install **Flash-Vent™ Flex** with soft fabric side facing out.
- When required by code, place **Flash-Vent™ Flex** on top of first weather resistant barrier, then staple or fasten near top edge.
- Lap second layer of weather resistant barrier a minimum of 3" over **Flash-Vent™ Flex** concealing fasteners.
- Bring **Flash-Vent™ Flex** out to the exterior edge of the veneer and trim as required, or place bottom edge of **Flash-Vent™ Flex** into weep slot of York's **Starter Screenshot™**.

